

## INFINITER™ #2000 GREEN LASER POINTER

### REPLACING THE BATTERIES

- Remove the laser pointer end cap.
- Remove used batteries and replace with two new AAA batteries.
- Insert batteries with the positive (+) side facing toward the end cap.
- Replace the end cap.



### OPERATING THE LASER POINTER

- Simply press the momentary push button to activate the laser pointer and release it to deactivate.



### WARNING

Use of controls or adjustments, or performance of procedures other than those specified herein may result in hazardous radiation exposure.

### SAFETY PRECAUTIONS

- Do not use this product where the temperature exceeds 35°C or goes below 15°C.
- It is normal. The performance of the green laser pointer to be slightly affected by temperature.
- This product may malfunction if immersed in water or exposed to high levels of humidity.
- Dropping or impacting this product can cause malfunction inside the device.
- Remove the batteries when this product is not to be used for a long period of time.
- For the high performance of the green laser, the alkaline batteries are strongly recommended.
- Keep this product away from children.
- The warranty will no longer exist once the product been taken apart.

### DISPOSAL OF BATTERIES

- Batteries must not belong to domestic waste.
- As a consumer you are obliged to give back all used batteries. You can hand in old batteries to the public assembly points in your municipality or everywhere you can buy batteries of the relevant sort.
- You will find the following symbols on harmful substances containing batteries:



www.infiniter.com

Copyright © 2002 Quarton inc. All Right Reserved

## INFINITER™ #2000

### Bedienungsanleitung

### BATTERIEWECHSEL: ( 2 x AAA Alkaline)

- Schrauben Sie das Ende des Lasers auf und erneuern Sie die Batterien.
- Schrauben Sie das Ende wieder zu. Bitte achten Sie darauf, dass der +/- Pol nach oben zeigt.



### BEDIENUNG

- Einschalten: Knopf drücken
- Ausschalten: Knopf loslassen



### ACHTUNG

- Manipulationen an den Einstellung, technische Veränderungen oder Laserleistung, die hier nicht beschrieben sind, können zu gefährlicher Laserstrahlung führen.
- Setzen Sie den Laserpointer nicht Temperaturen unter 15°C oder über 35°C.
- Tauchen Sie den Laserpointer nicht unter Wasser und setzen Sie ihn nicht höher Feuchtigkeit aus.
- Vermeiden Sie Schläge auf den Laserpointer und lassen Sie ihn nicht fallen. Eine Dejustierung der Optik oder Beschädigung der Laserdiode und der Elektronik könnten die Folge sein.
- Beachten Sie, dass der Laserpointer ein Lasergerät ist, die Batterien aussetzen, wenn es nicht sachgerecht benutzt wird.
- Halten Sie den Laserpointer Ausser Reichweite von Kindern.
- Die Garantie wird nicht gültig sein, wenn Manipulationen an den Einstellungen, technische Veränderungen oder Laserleistungen.

### ENSTORGEN LEERER BATTERIEN

- Leere Batterien gehören nicht in den Haushaltsmüll.
- Sie müssen leere Batterien stets dem Recycling zuführen. Geben Sie leere Batterien bei öffentlichen Sammelstellen Ihrer Gemeinde oder anderen, bevollmächtigten Sammelstellen ab.
- Sie finden die nachfolgenden Symbole für die in Batterien enthaltenen Schadstoffe:

Pb = Die Batterie enthält Blei  
Cd = Die Batterie enthält Kadmium



www.infiniter.com

Copyright © 2002 Quarton inc. All Right Reserved